



The Aqua Cow Rise System

by Kirby pat.pending

A NEW INVENTION TO RAISE DOWN -COWS



With the AQUA -COW -RISE -SYSTEM, you can float a down-cow back on it's legs harmless, without using any kind of clamps, belts or chains, which often only hurt the cow, and the cow will work against it. The AQUA -COW is a Natural way to get a cow back up on it's legs, using only warm water.

“IMPORTANT”

To get the best results of the AQUA -COW, please read this before operating the AQUA .. COW.



1. Position the AQUA-COW next to the down cow.
2. Take the two pins out to release the trailer from the container, make sure you hold the tongue down when pulling the pins out. Pull the trailer away and remove the two end doors.
3. Place the ramp at the end nearest the cow.
4. Place the rubber mat next to the cow, make sure it's straight with the container, so it will pull in easily.
5. Roll the cow onto the rubber mat.
6. Pull the mat, with the cow on it, into the container with a tractor or truck.



7. Close the two end doors, which seal the container.
8. Put the trailer back on. You will need two people, to pull the trailer tongue down into position. Insert the two pins.
9. Bring the AQUA-COW to a spot where you have warm water. A place where the ground is sand, dirt or grass, so when the cow is ready to walk out, the cow has very good footing, and doesn't slip or do the splits. **DON'T EVER LET HER OUT ON GRAVEL ROCKS OR CONCRETE, IT'S VERY IMPORTANT!**
10. Take the trailer back off, make sure there is two people holding the tongue down when you pull the pins out, because of the cow's weight.
11. Put a rope around her head to hold the head up, when filling with water.
12. Start filling the container with body temperature water.

13. Fill the container so the water is up near her hip, so the water will help warm up the muscles, and increase her circulation.



14. Let the cow stay in the water for about 6-7 hours.

15. Drain the water out slowly, so she can get use to her normal weight again, let her stay in the container without any water for about an hour. (Very important! Do not rush. Be patient.)

16. If she goes down with the water let her stay inside for at least 8 hours, and feed her there, before you fill with water again.





17. Before you let the cow out, you can take the back door off and milk her in the container if necessary.



18. Take the one door off and slowly let her walk out, try not to scare her so she won't try to jump or run. If she goes down, let her rest for a while and feed her, then put her back into the container.

19. This is not a quick process, some cows need more than one lift. Always pick up the cow as soon as possible after she went down, so she doesn't get stiff in her muscles or hurt herself by thrashing around.

This system has been used in the country of Denmark since 1982 and today it's the only system farmer's use to raise up a down cow, that shows how effective it is.

]Water capacity = 800 gal
without cow inside.

For More Info. Call ... Kirby Mfg.

Bob Smith Sales • 1-800-259-5303 • info@bobsmithsales.com
